



# ARCHERY

BUILT THE **BEST**. BY THE **BEST**. FOR THE **BEST**.



## A 440C STAINLESS STEEL OPEN-HOOK SEAR RELEASE.

THE HAWK COMES WITH AN ADJUSTABLE, ANGLED TRIGGER FOR BOTH TRAVEL AND TENSION. IT ALSO FEATURES AN INTERCHANGEABLE KNURLED POST AND SPRING-LOADED RETURN HOOK, SO THERE'S NO TIME WASTED DURING YOUR PERFECT SHOT. TRUST THE HAWK TO CLAIM THAT NEXT TROPHY.

### Available connectors:

SWIVEL STEM<sup>®</sup> — 11 LENGTH SETTINGS

FLEX CONNECTOR SYSTEM<sup>®</sup> — INFINITE LENGTH ADJUSTMENT

COMPLETE INSTRUCTIONS INCLUDED INSIDE PACKAGE. \*PATENTS PENDING.

101 TUG BRANCH ROAD / CLAY CITY, KY / 40312  
**B3ARCHERY.COM / 606.612.5215**



# ARCHERY

BUILT THE **BEST**. BY THE **BEST**. FOR THE **BEST**.

FLEX  
CONNECTOR<sup>®</sup>

SWIVEL  
STEM<sup>®</sup>



AUTO RETURN  
SINGLE-SEAR

440C STAINLESS  
OPEN HOOK



RELEASES • BROADHEADS • SIGHTS



## Adjustment Instructions

### Tension Adjustment

THE HAWK COMES WITH INTERCHANGEABLE SPRINGS FOR TENSION ADJUSTMENTS.

#### CHANGING SPRINGS

1. LOCATE THE SCREW ON THE NON-TRIGGER SIDE OF THE RELEASE HEAD.
2. BACK THE SCREW COMPLETELY OUT.
3. INSTALL DESIRED SPRING.
4. RE-INSTALL THE SCREW UNTIL IT BOTTOMS OUT IN THE RELEASE HEAD. **DO NOT OVERTIGHTEN.**

#### TRIGGER TRAVEL ADJUSTMENT

1. LOCATE THE TENSION/TRAVEL ADJUSTMENT SCREW BELOW THE TRIGGER.
2. INCREASE TRAVEL BY TURNING THE SET SCREW COUNTER-CLOCKWISE. DECREASE TRAVEL BY TURNING THE SET SCREW CLOCKWISE.
3. TEST YOUR B3 RELEASE AFTER EACH 1/16TH TURN OF THE SET SCREW. IT IS POSSIBLE TO SET YOUR TRIGGER TENSION TOO SENSITIVE IF TURNING THE SET SCREW TOO FAR (CLOCKWISE).

**ALL ADJUSTMENTS SHOULD BE MADE IN 1/16 INCREMENTS AND TESTED BEFORE SHOOTING.**

### Maintenance and Use

1. THIS RELEASE MAY BE USED WITH A STRING LOOP ONLY.
2. DO NOT USE THIS RELEASE WITH A METAL D-LOOP.
3. IF YOUR RELEASE BECOMES WET, ALLOW TO AIR DRY.

## Length Adjustments - *Patents Pending*

### SWIVEL STEM CONNECTOR

1. REMOVE THE 6/32 CAP SCREW FROM THE SIDE OF THE RELEASE HEAD.
2. SLIDE THE HEAD OF THE RELEASE TO THE DESIRED LENGTH, AND RE-INSERT THE SCREW INTO THE CORRESPONDING HOLE ON THE HEAD AND TIGHTEN.

**DO NOT OVERTIGHTEN THE SCREW. \*\*\***

**BE SURE TO INSERT THE SCREW INTO THE SIDE OF THE RELEASE HEAD WITH THE LARGER DIAMETER HOLES. \*\*\***

### FLEX CONNECTOR

1. LOOSEN THE 1/4-28 CONE POINT SET SCREW, WHICH IS LOCATED ON THE CENTER OF THE METAL STRAP BRACKET SEWN INTO THE RELEASE STRAP.
2. SLIDE THE FLEX CONNECTOR TO THE DESIRED LENGTH AND TIGHTEN THE SET SCREW. MAKE SURE TO KEEP THE SAFETY KNOT IN THE EXCESS NYLON.

**DO NOT OVERTIGHTEN THE SET SCREW. \*\*\***



**101 TUG BRANCH ROAD / CLAY CITY, KY / 40312**  
**B3ARCHERY.COM / 606.612.5215**



**BUILT THE BEST. BY THE BEST. FOR THE BEST.**