



ARCHERY

BUILT THE **BEST**. BY THE **BEST**. FOR THE **BEST**.

ROOK

INNOVATIVE DUAL-JAW RELEASE.

PROPRIETARY DESIGN FEATURING A STAINLESS STEEL LOAD JAW AND AN ANODIZED GUIDE JAW. THIS SYSTEM GIVES THE ACCURACY OF A SINGLE JAW AND THE SIMPLICITY OF A DUAL-JAW. A CURVED TRIGGER DESIGN WITH OUR PATENTED SWIVEL STEM CONNECTOR THAT WILL SWIVEL 360 DEGREES AND LOCK INTO PLACE TO MAKE FOR A QUIET CLIMB INTO YOUR TREESTAND.

SWIVEL STEM — 11 LENGTH SETTINGS

COMPLETE INSTRUCTIONS INCLUDED INSIDE PACKAGE.
PATENTED DESIGN.

101 TUG BRANCH ROAD / CLAY CITY, KY / 40312
B3ARCHERY.COM / 606.612.5215



ARCHERY

BUILT THE **BEST**. BY THE **BEST**. FOR THE **BEST**.

ROOK

BLACK STAINLESS
LOAD JAW

ANODIZED
GUIDE JAW

ADJUSTABLE
ROLLER SEAR

CURVED TRIGGER



RELEASES • BROADHEADS • SIGHTS

Adjustment Instructions

Trigger Travel Adjustment

1. LOCATE THE 4-40 TENSION/TRAVEL ADJUSTMENT SCREW AT THE TRIGGER'S BASE.
2. INCREASE TRAVEL BY TURNING THE SET SCREW CLOCKWISE. DECREASE TRAVEL BY TURNING THE SET SCREW COUNTER-CLOCKWISE.
3. ADJUSTMENTS SHOULD BE MADE BY 1/16TH TURN OF THE SET SCREW. ALWAYS TEST AFTER MAKING ANY ADJUSTMENTS.

PLEASE TEST AFTER ANY ADJUSTMENT.

DO NOT OVERTIGHTEN THE SCREW. ***

Length Adjustments

SWIVEL STEM CONNECTOR

1. REMOVE THE 6/32 CAP SCREW FROM THE SIDE OF THE RELEASE HEAD.
2. SLIDE THE HEAD OF THE RELEASE TO THE DESIRED LENGTH, AND RE-INSERT THE SCREW INTO THE CORRESPONDING HOLE ON THE HEAD AND TIGHTEN.

PLEASE TEST AFTER ANY ADJUSTMENT.

DO NOT OVERTIGHTEN THE SCREW. ***

BE SURE TO INSERT THE SCREW INTO THE SIDE OF THE RELEASE HEAD WITH THE LARGER DIAMETER HOLES. ***

Maintenance and Use

1. THIS RELEASE MAY BE USED WITH A STRING LOOP OR DIRECTLY OFF OF YOUR BOWSTRING.
2. DO NOT ALLOW RELEASE JAWS TO CONTACT METAL NOCK SETS OR METAL D-LOOPS.
3. ALLOW TO AIR DRY AND LUBRICATE ROLLER SEAR AS NEEDED.



101 TUG BRANCH ROAD / CLAY CITY, KY / 40312
B3ARCHERY.COM / 606.612.5215



BUILT THE BEST. BY THE BEST. FOR THE BEST.